

PAIRING OF META ROLLING CODE REMOTES

To program a new remote into any of the Meta car alarms using rolling code is required a 16 digit code and a working remote control. 16 digit hexadecimal code (contains numbers 0-9 and letters A - F) is supplied on the red plastic code card supplied with the unit. If code not available can Meta distributor read the code with special device from the memory of car alarm central unit.

When ordering a remote give the 16 digit code or send the picture of the code card to Meta distributor who will store the code to new remote control. To pair the remote with your Meta car alarm follow instructions on manual of your car alarm or ask detailed instructions for your alarm model from Meta distributor. Standard pairing procedure is described below:

1. Switch ignition ON.
2. With the working remote activate/ deactivate the alarm 8 times (8 x activate and 8 x deactivate)
3. After 16 press of button stops the remote to respond. All other remotes will be deleted at this point except the one used for the 16 transmissions.
4. Within 30 seconds press the button of new remote.
5. Press a button off all remotes to be enabled except the remote used for the 16 transmissions to enter the procedure.
6. To save paired remotes switch ignition OFF within 30 seconds of the last procedure.
7. Now all paired remotes and remote used to enter the procedure are working and not paired remotes are deleted from the memory of car alarm.

