


















Command functions	Cruise Control	Speed Limiter GC90(c)	Symbol	Acton	LED
Switch on:	Away briefly GC90(c) 2x low beep	Away long 1x low, 2x high beep			green
Activate:	Up briefly				orange
Increase speed					
Stepwise 1 km/h	Up briefly				orange
Continuously (GC30, GC55)	Up long				
Stepwise 10 km/h (GC90, GC90c)	Up long				
Decrease speed					
Stepwise 1 km/h	Down briefly				orange
continuously (GC30, GC55)	Down long				
stepwise 10 km/h (GC90, GC90c)	Down long				
Resume last set speed	down				orange
The preset speed can be programmed infour steps	<ol style="list-style-type: none"> 1. Switch Goldcruise on 2. Drive desired speed 3. Activate Goldcruise 4. Press button 1 or 2 until beep is audible 				
2 preset speed function	Press button 1 or 2				orange
Stand-by	pull				green
Switch off	Away briefly				off



General directions

John Gold recommend that the GoldCruise remains off when not in use.

The resume function can be only used in case:

- The driving speed is over 40 km/h
- The ignition has not been switched off in the meantime
- For GC90(c) there has not been a mode change between cruisecontrol and limiter.



Cruisecontrol directions

The GoldCruisecontrol will disengage when:

- Depressing the brake pedal
- Depressing the clutch pedal (if connected)
- Operate the || or Ⓢ function
- Speed reduction of 25% below the set speed
- Speed increase of 50% over the set speed
- Switching off the car ignition
- The brake fuse blows
- The brake lights bun out
- Do not activate the Goldcruise if the car is in neutral or the clutch pedal is depressed
- It is recomanded not to use the Goldcruise in heavy traffic or during bad weather
A cruisecontrol does noet apply the brakes! In case a drastical speed reduction is required, apply the brake pedal
- It is always possible to accelerate by foot while cruising. After releasing the pedal the car will resume to the previous set speed, unless the speed has been over 50% of the set speed



Speed Limiter directions

The GoldSpeedLimiter (GC90, GC90c) can be used in 4 different configurations (GC90, GC90c):

1. Fixed top speed (limit)
2. Voluntary / variable limit
3. Combination of fixed and voluntary limit
4. Acoustic warning

The voluntary speed limiter will desengage when:

- Operating the || function
- Switching Ⓢ function
- Switching off the car ignition
- Releasing and quickly pressing the accelerator pedal

Version 0413

John Gold International BV© 2013

100% Recycling-Paper

