

Manual CM50 Command Module

Function	Act	Cruise Control		Limiter		
switch on	1	☆	short	+	long	
SWITCH OIL		led	green	led	green	
		4)))	2x low	4)))	1x low, 2x high	
activate	.1				led orange	
+						
accelerate	1		short (<1S) 1 kph			
↑			long (1s>) 10 kph		led orange	
decelerate	,					
decelerate —			short (<1S) 1 kph		led orange	
\Box		\bigcirc	long (1s>) 10 kph		ieu orange	
resume	\ 0					
₽					led orange	
de-activeren						
II					led green	
switch off	1 0					
					led off	
mome=/-		program:	hold for 2 sec.			
memory's		usage: press briefly				
\bigcirc		! For the limiter and Cruise Control different speeds can				
	be programmed					

Cruise Control

- The Cruise Control can be used from 35 kph
- Don't use the Cruise Control during bad weather
- The Cruise Control does not slow down! But only release the throttle
- It's always possible to accelerate in the interim by pressing the throttle. After that the
 the car will resume the set speed if the speed has not been increased by more than 50%
 compared to the set speed

The Cruise Control will switch off with:

- Braking
- Pressing the clutch (if connected)
- De-activate
- Switch off the Cruise Control
- Decrease speed by 25% compared to the set speed
- Increase speed by 50% compared to the set speed
- Switch off the ignition

Limiter

The limiter can be used from 35 kph

The speed limiter will switch off with:

- De-activate
- Switch off the speed limiter
- Throttle kick down
- Switching off the ignition